




# WIN10 Drive MASTouch Uninstall


1. Open the "control panel" > "Programs and Features" > "MAStouch USB Touchscreen Driver" > "uninstall".



(If this step is not completed, please repeat it.)






2. Right button “this PC” > “manage ”> “Device manager ”> “more Actions ”> “view”> “show hidden device”.





3. “human interface Devices” > “MASTouch USB Touchscreen”> Right button it, select “uninstall device”



8. Check “Delete the driver software for this device” > click “uninstall device”.

